

MR. CLEAN® MAGIC ERASER



Mr. Clean® Magic Eraser is a highly effective cleaning tool made of a chemical-free, innovative material that erases dirt easily. It easily and thoroughly breaks up tough dirt with just water alone. It penetrates surface grooves to clean trapped dirt and grime. It is available in two versions; Original Pad and DUO Pad. Mr. Clean® Magic Eraser DUO has an absorbent blue side for wiping up everyday messes.

Mr. Clean® Magic Eraser Original Pads and DUO Pads are available in 4 count packs, 6 packs in a case.

TASK AREAS

- Walls
- Floors
- Non-Finished surfaces:
 - Tables
 - Counter Tops
 - Sinks