

# Air Freshener Maintenance

## Products Needed



DCT Easy  
Fresh Air  
Freshener

## Tools Needed

- No Tools Required

## Frequency

Monthly



## Special Directions

Procedure assumes air freshener base unit is already installed on door, wall or other fixture

## Replace Cover and Battery



**NOTE:** Pushing UP on bottom tab may help to loosen cover so it can be removed more easily.



## LED Light Signal:

- Blinking Green = Program Running
- Blinking Red = Change Cover and Battery Immediately.
- No LEDs Blinking = Change Battery and Cover.
- Audible Alert = Overdue; Change Cover and Battery Immediately.