

# Installing the Hand Soap Reservoir and Troubleshooting Tips

## Products Needed



Safeguard®  
Liquid Anti-  
Bacterial Hand  
Soap

## Frequency

**Special Directions**  
(CCT 106)

## Link to Training Video



Scan the QR code or click the link below to see the training video.


<https://bit.ly/444WbgQ>


## Part Needed




Daansen hand soap dispenser reservoir

## Install the Reservoir

- 



Open the cover by locating the white cover release under the dispenser. Push **UP** on the release to open.
- 

Insert the reservoir into the dispenser.
- 

Twist **OFF** the reservoir cap.



Confirm the white tip ridge is properly seated in the slot. Tip outlet must extend below the dispenser. **Incorrect installation will damage the reservoir tube or tip and cause soap leaks.**



Pour Safeguard Liquid Hand Soap into the refillable reservoir.



Twist **ON** the reservoir cap and close the cover.



Push the gray push bar until you see a dose of hand soap.

## Troubleshooting

- Use **care NOT** to **OVERPOUR** the soap.
- Do **NOT** throw away the reusable reservoir.

**Troubleshooting Tips** for product **NOT** dispensing.

- **Reservoir Nozzle** – Ensure the white tip ridge is properly positioned into the slot. Tip outlet must extend below the dispenser.
- **Reservoir Tube** – If the rubber tube is flat, the reservoir tube (outlet tip assembly) needs to be replaced.
- **Push Bar Hinge** – If the gray push bar is cracked or missing, the push bar needs to be replaced.
- **Dispenser Push Bar Hinge** – If the dispenser cover or hinge is cracked, the entire dispenser needs to be replaced.



# Installing the Hand Soap Reservoir and Troubleshooting Tips

**Troubleshooting Tips** for leaking hand soap,

- **Reservoir Tube Tip** – If the white plastic dispensing nozzle tip is cracked or missing, the reservoir tube (outlet tip assembly) needs to be replaced.
- **Reservoir Tube** – If the rubber tube is cracked or missing, the reservoir tube (outlet tip assembly) needs to be replaced.
- **Reservoir** – If the cap is missing or a crack or leak is in the plastic reservoir, the entire reservoir needs to be replaced.

To order a replacement hand soap dispenser, reservoir tube (outlet tip assembly), push bar, or reservoirs visit [pgprosupplies.com](https://www.pgprosupplies.com)

