

# Install Manual Safeguard Gel Hand Sanitizer Dispenser

## Products Needed



Safeguard®  
Dispenser -  
Manual



Safeguard®  
Gel Sanitizer

## Frequency

## Special Directions

### Link to Training Video



Scan QR code to see video.

<https://bit.ly/3BKnjvr>

### Install Drip Tray If Available



Install the drip tray to the back of the dispenser before installing the dispenser to the wall.

### Unpacking Dispenser Box



Open the shipping box. Locate the manufacturer's instructions for operation. Refer to these instructions for further detail.



Locate the clear bag that contains various parts and set aside. Remove the white plastic key and set aside.



Remove the labels from the parts bag. Apply the "Hand Sanitizer" label by centering it across the width of the dispenser between the Safeguard logo and the cover window.

### Install Dispenser

#### American Disabilities Act (ADA) Requirements:

To meet ADA requirements, install all hand soap/sanitizer dispensers so that the top of the push bar is at a 40-inches from the floor.



Open the dispenser cover from the top using the white plastic key by pushing down through the key holes.



Install the dispenser to the wall. Allow 4" for the top of the dispenser to be accessed and 12" for the cover to flip open.



Remove the cap at the end of the [Safeguard Gel Hand Sanitizer](#) cartridge.



Install a hand sanitizer cartridge into the dispenser. Confirm the white pump attachment at the bottom of the cartridge is seated properly and the two ends click into place.



Close the dispenser cover.



Place your hand under the dispenser. Push the gray bar to prime the hand sanitizer pump until you see a dose.

