CCT 210 OPL Replace Empty Product Container

Tools Needed

- Bucket Wrench [Sized for 5 gallon or 15 gallon]
- Gloves, Disposable
- Goggles, Safety

Frequency

Special Directions

Disposable gloves and safety goggles must be worn when handling concentrated chemicals.

Link to Training Video



Scan QR code or press link to see the training video.

https://bit.ly/3vX9fVa

NOTE: This phone fix closely matches a generic OPL wall chart usually hung in the laundry area called "To Replace an Empty Container" 0360– 0014

The procedure steps are the same for a 5 gallon or 15 gallon product container



Put on gloves and goggles.



Visually check the remaining level of the product.



REMOVE cap from empty container.


LOCATE the bucket wrench stored above the pump stand or hanging near it.

NOTE: Some locations may have lost the bucket wrench. A hardware store hand tool like a Channellock wrench can be used if the bucket wrench is missing.

The 15 gallon containers have a different style bucket wrench than the 5 gallon containers. Currently, there are two different style 15 gallon bucket wrenches in the system.



REPLACE with a new full container. Use the bucket wrench to **REMOVE** the white shipping cap.



TWIST ON the mating cap. Visually INSPECT for improper seating. PUSH DOWN on the cap while turning until you can hand tighten it while properly seating the mating cap.



Place white shipping cap on empty container before disposal.