# **OVEN**

## **Tools Needed**

- · Clean Towels
- Utility Bucket
- Non-Abrasive Pad
- · Eye Protection
- Oven Mitts
- Rubber Apron
- Rubber Gloves

## **Product Needed**

DCT Oven Cleaner



# FREQUENCY OF CLEANING: Weekly.

SPECIAL DIRECTIONS FOR THIS TASK: Wear hand, body and eye protection.



#### STEP 1

• Turn oven off, and let cool for 45 minutes.

NOTE: For ovens equipped with cooldown mode, place blower switch in cooldown position and let cool for 45 minutes.



- Unplug oven from electrical outlet. If outlet is not accessible, turn power off at circuit breaker.
- Turn on overhead exhaust fans.



#### STEP 2

- · Put on oven mitts.
- Remove all oven racks, and take them to the 3-compartment sink to be cleaned.
- Remove any aluminum foil from the fan guard.
- · Remove oven mitts.



### STEP 3

 Place foaming sprayer onto DCT Oven Cleaner bottle and tighten until snug.

NOTE: Put on eye protection, rubber gloves, and rubber apron for Steps 4–6.



## STEP 4

 Foam DCT Oven Cleaner onto all interior and exterior oven surfaces including doors.

NOTE: DCT Oven Cleaner is most effective when applied while oven surfaces are still warm (130°-150°F).



• Let soak for 5-10 minutes.



### STEP 5

 Scrub surfaces with non-abrasive pad to loosen soil.



#### STEP 6

- Fill a clean utility bucket with warm rinse water, and place a clean towel into the utility bucket.
- Carry utility bucket to the location of the oven.



#### STEP 7

- Using the clean towel in the utility bucket, wipe oven surfaces to pick up loosened soil.
- When towel becomes heavily soiled, rinse it thoroughly in the utility bucket.
- Repeat process until all residues are removed.



# STEP 8

· Replace oven racks.



### STEP 9

• Wipe down the inside and the outside of the glass doors with clean water.



# STEP 10

- Plug the oven into the electrical outlet.
- If the circuit breaker was turned off, turn it back on.



## **STEP 11**

- Remove protective equipment.
- Wash hands before returning to service area.