1 of 2

Tools Needed

- Eye Protection & Gloves
- Flathead Screwdriver
- Side or Hose Cutter
- Zip Tie(s)

Frequency

Special Directions

Gloves and eye protection must be worn if handling concentrated chemicals. (CCT 219)

Link to Training Video



Scan the QR code or click the link below to see the training video.

https://bit.ly/3KlwgnK

Parts Needed

Squeeze tubes will need to be replaced "as needed" or every 6 months.

> Seko Mini Laundry Squeeze Tube(s) -**OPL Mini** 03539900090071



Sprite Pump Laundry Squeeze Tube(s) -**Sprite Pump** 035380030NFB6SIL

Remove the Pump Cover

These pumps and approved products (Tide SC or 2X Detergents and Tide Stain and Odor Eliminator) are used with "home residence style" top load washers.



Put on eye protection and gloves.

For the Sprite

aside.

aside.

pump, unplug the

pump. Loosen the

thumb screw on the

orange cap and set

For the Seko Mini

pump, unplug the

to loosen the set

screw. Remove the

blue cover and set

flathead screwdriver

pump use a







Slide a squeeze tube barb out of the notch and the pump. Note the orientation of the barb and the notch. Repeat for the other side. Dispose the used squeeze tube.



Use the cutter to remove the zip ties from the supply tubing located under the pump at the intake and discharge barbs.




Remove the intake and dischage tubing from the pump barbs.



Install the new squeeze tube in the same orientation as before. Ensure the notch and barb are fully seated on each side.





Replace the cap (Sprite) and cover (Seko Mini) onto the pumps.

> P&G **Professional**

©2023 Procter & Gamble. All Rights Reserved. Unauthorized reproduction prohibited. (Last Updated: 04/25/2023) Region: United States/Canada

How to Replace Squeeze Tubes [Sprite & Seko Mini]



Plug in the controller. For the Sprite pump, press the ENTER button to prime the supply tubing. For the Seko Mini pump, press the red button on the remote to prime the supply tubing. Ensure the squeeze tube functions properly and product is dispensing.



2 of 2

©2023 Procter & Gamble. All Rights Reserved. Unauthorized reproduction prohibited. (Last Updated: 04/25/2023) Region: United States/Canada