WALK-IN COOLERS

Tools Needed

- Clean Towels
- · Non-Abrasive Pad
- · Broom and Dustpan

Product Needed

Spic and Span® Disinfecting All-Purpose Spray and Glass Cleaner (3-in-1)



FREQUENCY OF CLEANING: Weekly.

SPECIAL DIRECTIONS FOR THIS TASK: If sensitivity to cleaning solutions is a concern, wear disposable gloves.



STEP 1

- Sweep walk-in cooler before starting.
- · Discard debris in trash container.



STEP 2

 Move the food to another rack or shelf to avoid getting any cleaner on food containers.



- Spray 3-in-1 all-purpose cleaner from spray bottle onto clean towel or non-abrasive pad.
- Scrub racks until clean.



STEP 3

 Pull storage racks away from wall to clean walls behind racks.

CAUTION: If racks are not on wheels, get assistance to move racks.

- Spray 3-in-1 all-purpose cleaner onto wall and door gaskets.
- Wipe with clean towel.



STEP 4

- Clean the wall surfaces by scrubbing from the bottom of the wall and moving up.
- Replace towel when it becomes dirty.

NOTE: Turn off fan prior to cleaning. Be sure to wipe the fan guards and light shields.



STEP 5

- While the storage racks are pulled out from the wall after cleaning the walls, sweep the floors and discard debris.
- Clean the floors following the <u>Floor</u> <u>Cleaning Procedure</u>.



STEP 6

- Push the storage racks back against the wall.
- Clean the center of the floor using the Floor Cleaning Procedure.
- · Air-dry surfaces.



STEP 7

- If used, remove and discard disposable gloves.
- Wash hands before returning to service area